




EpilogLaser

19000Series

Fusion Ascent Laser System Manual | Model 19000

Original Instructions



Register your system now for driver updates and access to our Training Suite!

EPILOGLASER.COM/REGISTER

Knowledge Base: support.epiloglaser.com

System Registration: epiloglaser.com/register/

Driver/Firmware: epiloglaser.com/support/drivers/

TABLE OF CONTENTS

FIRE WARNING	1
INTRODUCTION	2
How to Use This Owner's Manual	2
Icons Used in this Manual.....	2
General Description:	2
Intended Use:	3
Possible Misuse:	3
Operation of the Ascent laser system:	3
Ascent Workstation:	3
INTRODUCTION	3
SECTION 1: SAFETY	5
Laser Safety	5
Electrical Safety.....	6
Safety Features and Regulatory Compliance.....	7
Fusion Ascent Care Instructions	13
Fusion Ascent Lifting Instructions	13
SECTION 2: GETTING STARTED	15
1. Unpacking	16
2. Choose Where to Locate the System	19
3. Connecting the Exhaust.....	20
4. Connecting Electrical Power	22
5. Connecting the Laser to Your Computer	22
6. Power on the Laser	23
7. Set the IP Address.....	25
8. Install the Software Suite & Set Up Your Laser.....	28
9. Sign Up for Driver Updates and Register Your System	29
SECTION 3: CONTROL PANEL	31
SECTION 4: SYSTEM FEATURES	43
IRIS™ Camera Positioning System	43
Touch Screen.....	43
Air Assist	44
Auto Focus vs Manual Focus.....	45
Key Switch	46
Red Dot Pointer.....	46
Emergency Stop Button	47
Vector Cutting Table	47
Exhaust Plenum	47
SECTION 5: SYSTEM MAINTENANCE	49
Reduce Fire Risk with a Clean Laser.....	49
Cleaning the Optics on the Fusion Ascent	51
Cleaning the Exhaust Plenum.....	56
Laser Tube.....	57

TABLE OF CONTENTS

SECTION 6: SPECIFICATIONS	59
Fusion Ascent 12/24 Laser Technical Specifications.....	59
Fusion Ascent 36 Laser Technical Specifications	60
Compatibility.....	61
Recommended PC.....	61
About The CO2 Laser Source	62
Federal Communications Commission (FCC) Notice	63
SECTION 7: TECHNICAL SUPPORT	65
Contacting Technical Support	65
Frequently Asked Questions	66
Join Epilog Laser’s Online Community	68
APPENDIX A: WARRANTY STATEMENT	69
Warranty Statement for the Fusion Ascent Laser.....	69
APPENDIX B: MATERIAL SETTINGS	71
Fusion Ascent Suggested Material Settings (CO2).....	71
Fusion Ascent Suggested Material Settings (Fiber)	74
APPENDIX C: SYSTEM CALIBRATION	79
Calibrating the Auto Focus.....	79
Camera Calibration	82
Carriage Camera Calibration.....	82
Overhead Camera Calibration	83
Machine Settings:.....	83
INDEX	87

FIRE WARNING

Fire Warning



Your laser system uses a high intensity beam of light that can generate extremely high temperatures when it comes into contact with the material being engraved, marked or cut. Some materials are extremely flammable and can easily ignite and burst into open flame setting the machine afire. This open flame is very dangerous and has the potential to destroy not only the machine, but the building in which it is housed.

Experience shows that vector cutting with the laser has the most potential to create an open flame. Many materials are susceptible to igniting, but acrylic, in all its different forms, has been shown to be especially flammable when vector cutting with the laser.

Please read the following warnings and recommendations and follow them closely at all times!

- **Stay with the laser.** Never operate the laser system while unattended.
- **Keep the area clear.** Clean around the machine and keep the area free of clutter, combustible materials, explosives, or volatile solvents such as acetone, alcohol, or gasoline.
- **Be prepared with a fire extinguisher.** Always keep a properly maintained and inspected fire extinguisher on hand. Epilog recommends a CO2 fire extinguisher or a multi-purpose dry chemical fire extinguisher.
- **Use Air Assist.** Always use the system's Air Assist feature when vector cutting.
- **Use caution when vector cutting.** Many materials have the potential to suddenly burst into flames when cut with a laser – even materials that may be very familiar to the user. Always monitor the machine when it is operating.
- **Clean the laser.** A buildup of cutting and engraving residue and debris is dangerous and can create a fire hazard in its own right. Keep your laser system clean and free of debris. Regularly clean underneath the Vector Cutting Table to clean any small pieces that have fallen through the grid.

INTRODUCTION

How to Use This Owner's Manual

Thank you for purchasing an Epilog Fusion Ascent Laser system. Your Epilog system has been designed to be easy to operate, but you will utilize it to its fullest potential by taking some time to read this owner's manual prior to use. You will be ready to use the Epilog Laser system as soon as you read the first few sections. Then you can refer to topics in the remaining sections, as you work.

Icons Used in this Manual

Look for these symbols to help you find valuable information throughout the text:



Helpful notes to keep in mind when running the laser!



This icon signifies advice you can try that will save you significant time.



This icon highlights current contact information for receiving help.



Warnings and cautions to keep in mind when running the laser.



This icon indicates the potential for fire damage when operating the laser.

General Description:

The Epilog Ascent Model 19000 laser system uses a flying optic (plotter) beam delivery mechanism to deliver a laser beam to the material being processed on the work surface of the machine. The flying optic beam delivery system moves the laser beam across the work surface and fires the laser when instructed to do so, vaporizing the material being processed. The Ascent emulates a paper printer in that it receives data from a graphics software program, interprets that data, and then instructs the machine where to move the flying optics and where to fire the laser.

INTRODUCTION

Intended Use:

The Epilog Ascent laser system, Model 19000 is intended for use to engrave, cut and mark a wide variety of materials including, but not limited to, wood, plastic, acrylic, glass, leather, rubber, coated metals, anodized aluminum, textiles, paper, etc.

Possible Misuse:

The Epilog Ascent laser system is not designed to process PVC or other materials that produce noxious byproducts when engraved, cut, or marked. The warranty is voided if PVC is processed.

Operation of the Ascent laser system:

The Epilog Ascent is only to be used by trained and qualified personnel. Personnel that have not been trained in the operation of the computer, graphics software program, or the laser system must enlist the help of a qualified operator to operate the laser system.

Ascent Workstation:

The Epilog Ascent is comprised of the Ascent laser system, an air assist pump, a computer with graphics software, and an exhaust system.

SECTION 1: SAFETY

Laser Safety

The Epilog Model 19000 Laser Systems are a Class 2 laser product, as defined in International Standard EN 60825-1:2014/A11:2021.

The Epilog Model 19000 complies with 21 CFR 1040.10 and 1040.11, the Federal Performance Standards for Light-Emitting Products, except for deviations pursuant to Laser Notice No. 56, dated July 16, 2001. The Center for Devices and Radiological Health, of the US FDA, issued Laser Notice No. 56 to permit manufacturers to classify and manufacture their products in accordance with the International Standard.

In Class 2 mode the output of the embedded laser is fully contained. The laser cabinet has safety interlocks that turn the laser off if any access door is opened during operation, and no special precautions are necessary to operate the laser safely. Access doors are interlocked and can be opened without the use of a tool. Any interlocked door that is opened while the machine is operating will immediately stop the laser from firing.

Access panels are not interlocked and require a tool for opening or removal. Access panels should always be installed when the laser is operating. Never operate the laser system with an access panel removed.

The visible output beam of the Laser Diode Pointer (Red Dot Pointer) is accessible to the operator. While this device employs the same technology as the familiar laser pen-pointers, like them it is potentially hazardous if its beam is directed into the eye. We have made every effort to make the Laser Diode Pointer (Red Dot Pointer) as safe as possible. Its beam path is located well inside the cabinet, and under normal conditions, no hazardous levels of laser radiation can escape.

The operator of the Epilog Model 19000 should observe the following general precautions:



DO NOT disassemble the machine or remove any of its protective covers while the unit is plugged in.

DO NOT attempt to defeat the door interlocks.

DO NOT view directly into the beam of the Laser Diode Pointer (Red Dot Pointer).

DO NOT operate the Laser Diode Pointer (Red Dot Pointer) without the machine's focus lens in place. If the unfocused beam strikes a reflective surface, it could be directed out of the cabinet.

Caution – Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

The standard reference for laser safety is the American Standard for the Safe Use of Lasers, Z136.1-2022, developed by the American National Standards Institute (ANSI). This reference is the basis for many of the federal regulations for laser and laser system manufacturers, and for the Occupational Safety and Health Administration (OSHA) laser safety guidelines. It contains detailed information concerning proper installation and use of laser systems.

While the ANSI standard itself does not have the force of law, its recommendations, including warning signage, training, and the designation of a laser safety officer, may be compulsory under local workplace regulations when operating laser systems above Class I. It is the operator's responsibility to ensure that the installation and operation of the Epilog Model 19000 Laser System is performed in accordance with all applicable laws.

SECTION 1: SAFETY

Copies of ANSI Standard Z136.1-2022 are available from Epilog Corporation or from:



Laser Institute of America
12424 Research Parkway, Suite 125
Orlando, FL 32826
(407) 380-1553

Electrical Safety

The AC input power to the Epilog Model 19000 Laser System is potentially lethal and is fully contained within the cabinet.



- **DO NOT** open any of the machine's access panels while the unit is plugged in. Opening a panel may expose the operator to the unit's AC input power.
- **DO NOT** make or break any electrical connections to the system while the unit is turned on.

Fusion Ascent Electrical Specifications

Model	Wattage(s)	Voltage	Amp draw-MAX
Ascent 12	30, 40, 60	115-240	12A
Ascent 12	30, 40, 60	220-240	6.4A
Ascent 24/36	40, 60, 80	115-240	12A
Ascent 24/36	40, 60, 80	220-240	6.4A

SECTION 1: SAFETY


Safety Features and Regulatory Compliance

Epilog has incorporated specific safety features into the Model 19000 Laser System in order to meet the requirements of 21 CFR 1040 and the International Standard EN 60825-1. These safety features include:

- A safety enclosure (cabinet), which fully encloses the engraving laser and its beam path in Class 2 mode.
- Dual redundant interlock systems that turn off the engraving laser when the window is opened.
- A visible emission indication when the Laser Diode Pointer (Red Dot Pointer) is operating. There is an LED indicator on the machine's top touch screen panel.

21 CFR 1040 and EN 60825-1 require that certification, identification, and warning labels be placed on laser products. Reproductions of labels on the Epilog Model 19000 Laser System follow, with their locations specified:

1. **Certification/Identification Plate:** This engraved plate is located on the right side of the machine's cabinet.








2



2. **Warning Logotype:** Indicates that invisible and visible laser danger is present if the cover is opened or removed.


SECTION 1: SAFETY




3. **Descriptive Label:** This label identifies the classification of the Model 19000 in accordance with 21 CFR 1040.10 and EN 60825-1.
4. **Non-interlocked Protective Housing Safety Labels**
5. **Defeatably-interlocked Protective Housing Safety Labels**
6. **Electrical Safety Label:** Potentially dangerous electrical exposure is present if the cover is removed.
7. **Fuse Label**
8. **Mechanical Safety Label:** Dangerous rotating moving parts are accessible if this cover is opened or removed.
9. **Consult Manual Label:** There is additional information in the manual.
10. **Aperture Safety Label**
11. **Power Labels:** Indicates the correct input power of the main electrical connection.
12. **Fire Hazard:** Indicates machine can ignite materials during operation. Warns operators to stay attentive, remove combustible debris, and follow fire-safety procedures

SECTION 1: SAFETY

The following diagrams show the location of each specific label.



SECTION 1: SAFETY



SECTION 1: SAFETY

Fusion Ascent FCC:

Supplier's Declaration of Conformity 47 CFR Paragraph 2.1077 Compliance Information

Laser Materials Processing System Model 19000

Epilog Laser Corporation
16371 Table Mountain Parkway
Golden, CO 80403

Telephone: (303) 277-1188

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation..

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

This product contains a Certified transmitter module (wireless network interface), FCC ID: Z64-WL18DBMOD

SECTION 1: SAFETY

Do and Don't



Don't

Do Not Run the Laser Unvented: Never operate the machine without a properly operating vent to the outside or to a filtration unit! Most material will only produce an irritating smoke when engraved. Some materials, including but not limited to paint, varnish, composition board and plastics, produce compounds that can be harmful if concentrated. A properly installed vent is the only way to ensure that problems do not occur.

Do Not Engrave or Cut PVC: Never engrave or cut **any material** containing PVC or vinyl. When engraved, a corrosive agent is produced that will destroy your machine. Your warranty will be void if your machine is damaged by corrosion from engraving or cutting PVC or Vinyl.

Do Not Operate Machine While Unattended: Never operate your machine without someone watching the system. There is a significant risk of fire if the machine is set improperly, or if the machine should experience a mechanical or electrical failure while operating.

Do Not Vector Cut While Machine is Unattended: Never laser cut any material with the laser without someone watching the system. Because vector cutting moves relatively slowly compared to raster engraving, a tremendous amount of heat is applied to the material being cut. This buildup of heat can cause significant fire risk and the machine should always be monitored. Additionally, the Air Assist should always be turned on when vector cutting to reduce the risk of fire.



Do

Clean the System: Please allow a few minutes a week for cleaning your machine. Just a small amount of effort at the end of the week will pay off with years of trouble-free operation of your machine.

See the section “**SECTION 5: SYSTEM MAINTENANCE**” on page 49 for specifics.

SECTION 1: SAFETY

Fusion Ascent Care Instructions

- **Operating altitude** – 3,500 meters max
- **Relative Humidity** – 100% max, non-condensing
- **Disposal** – The Ascent 12/24/36 is recyclable. Do not dispose of the machine in the trash. Electronic components should be disposed of in accordance with regional directives.
- **Protective Grounding** – Notice: Only connect the Ascent to a power source having a three-wire grounded outlet.



Note: The Ascent 12/24/36 is not suitable for wet locations or pollution degree greater than 2.

Fusion Ascent Lifting Instructions

Ascent 12 / 24 / 36

The Ascent 12, 24 & 36 laser systems can be lifted and carried using two or more people on the sides of the machine.

SECTION 2: GETTING STARTED

Setting up your Epilog Laser System is easy to do! If you've ever installed a paper printer, this is only slightly more difficult. The following information will help you understand the entire system and how it works.

The Fusion Ascent laser systems consist of the following components:

1. Fusion Ascent Laser System
2. Epilog USB thumb drive with Software Suite installation files
3. USB and Ethernet Cables
4. Training Suite Kit

You will also need:

1. A computer or laptop.
2. An exhaust fan: The exhaust fan is mandatory and is used to remove smoke and debris from the work area. The exhaust air can be ported to the outside or into a filter box.

Follow these steps to set up your Epilog Laser system after unpacking it:

1. Choose where to locate the system.
2. Connect the exhaust system to your laser.
3. Connect the electrical power.
4. Connecting the laser to your computer.
5. Power on the laser and select your settings in the unboxing wizard.
6. Sign up for driver updates and register your system at **www.epiloglaser.com/register**.

Class 4 Kit

The Optional Class 4 Kit is sold separately, contact your Epilog Distributor for more information.


SECTION 2: GETTING STARTED

1. Unpacking

Fusion Ascent


Unpack the laser system from the crate provided by Epilog. Please be sure to hold on to all packing materials and crating in case you need to move the system in the future.

1. Start by using scissors or a utility knife to cut the box straps. Stand clear of the straps, as they are under high tension and may pop out at high speed when cut.



Now remove the strapping and the wooden box topper.

2. Pull the box up and away from the pallet.




3. Cut the tape that's holding the bag closed, then spread the bag over the sides of the machine.
4. If you purchased a stand with your machine and you'd like to use it as the base for your Fusion Ascent machine, assemble the stand now, before continuing on with this lesson.
5. The Fusion Ascent weight ranges from 147-212lbs. With the help of an additional person, lift your Ascent laser system from the pallet and place it on a sturdy, level surface.
6. Once you've removed the machine from the pallet, remove the plastic bag.



SECTION 2: GETTING STARTED

7. You'll find the included items and materials stored underneath:

- Power cord
- Ethernet cord
- USB cord
- Software Installation USB
- Quick Start Guide
- Owner's Manual
- Training Suite Signup Card and Kit
- Vendor Material Sample Kit
- Lens Cleaner
- Laser Beam Alignment Target
- Camera Calibration Sheet



SECTION 2: GETTING STARTED



SECTION 2: GETTING STARTED

2. Choose Where to Locate the System


Cooling Requirements and Operating Temperatures

All Epilog Laser systems use air-cooled laser tubes. Laser technology is such that the laser tubes generate a lot of excess heat and the tubes must be cooled for proper operation. There are cooling fans located on both sides of the laser. The fans and vents should always be clear of restrictions and should never be covered.



Warning: The cooling fans and vents are located on both sides of the Fusion Pro and should never be covered or blocked in any way. Lasers that overheat will not operate properly and may begin to produce erratic laser output or possibly complete failure.

Ambient air temperature where the laser system is operating should not exceed 90 degrees F (32 C). Operating in an environment where the ambient air temperature is above 90 degrees F (32 C) will void the Epilog warranty. **For more information, see the “Warranty Statement for the Fusion Ascent Laser” on page 69.**



SECTION 2: GETTING STARTED

3. Connecting the Exhaust

In this manual, the term “exhaust” refers to either an exhaust fan or a filter unit and the term “exhaust” is used for simplicity. The important point is that it is mandatory that an exhaust unit or filter system is incorporated as part of your laser system. Never operate your laser system without a properly functioning exhaust. The exhaust removes the dust, debris and smell from the engraving cavity and exhausts it to the outside of the building or to the filter unit. Prior to the installation of the laser system, you may need a contractor to install the exhaust system. The blower should be mounted outside your building for noise considerations. Ideally, the blower should not be more than twenty feet (6 meters) from the laser. You should provide a metal duct (flexible aluminum or galvanized sheet metal) from the blower to the laser.

- **All Epilog Ascent 12/24 as well as 36 laser systems** require an exhaust fan that is rated at a minimum of **350-400 CFM** for external exhaust.

Epilog provides recommended exhaust flow rates (CFM) only for direct ventilation exhaust systems that are ported to the outside. Please note that this is also a recommendation and not a requirement, because factors such as length and type of tubing from the Epilog laser to the exhaust fan and from the exhaust fan to the outside of the building can produce significant losses on the true amount of air that is drawn from the Epilog laser.

Exhaust flow rates (CFM) for filter systems are not specified in this document. However, exhaust flow rates for filtration units will be lower than a direct ventilation exhaust system because filters are designed to be placed directly adjacent to the laser system and do not exhibit the air-flow losses that are typically found with direct exhaust fans. Epilog has worked with most major filter manufacturers to recommend a specific filter system for each model of Epilog laser. Please contact your Epilog distributor to match a filter to the Epilog laser system you are using.



Note: Remember to put the blower switch for the laser system in an obvious and accessible place so it can be routinely switched on prior to using the engraver. Please connect the exhaust blower to the laser as shown on the following pages.


Remember, you may need a contractor to install the exhaust. This must be done PRIOR to installation of the laser system.



Warning: It's important that either rigid or flexible metal ducting be used for all connections leading to and from the laser system and the exhaust fan. Vinyl, plastic, or any type of “soft” ducting is potentially flammable and should not be used unless provided by the filtration system manufacturer and made from fire-proof materials.

SECTION 2: GETTING STARTED

Fusion Ascent 12/24/36 Exhaust Setup:



Epilog Exhaust/Filter Connections

There is one 4" (102 mm) port attached to the back of the Fusion Ascent 12/24/36 laser systems.



Check your exhaust system for leaks. Most small leaks can be remedied with duct tape. **DO NOT OPERATE** your laser with inadequate or leaking exhaust.

The drawings above show the typical exhaust setup. The left drawing shows the exhaust near the machine and the right drawing shows the exhaust fan on the roof. Where the exhaust fan is placed is a choice of personal preference. Some users like the exhaust fan outside because of noise considerations.

Air Assist Pump

Epilog's optional Air Assist Pump is available to work with the included Air Assist features of the laser systems, directing a constant stream of air to your cutting surface to remove heat and combustible gases from the work area. The Air Assist Pump feeds 30 psi of air through the Air Assist structure.


The pump can be connected quickly to the machine via inlet and outlet ports on the compressor and the laser system. The Fusion Ascent systems have a port on the back of the machine to hook up an Air Assist Pump.



SECTION 2: GETTING STARTED

4. Connecting Electrical Power

Epilog supplies the appropriate power cord for the system you ordered. The power cord is found in the accessory package with your machine. The power cord for the laser plugs into the power receptacle located on the right side of the machine in the rear corner. It is recommended that a dedicated 15-amp circuit be used if available.



Electrical Connection
220 V-50/60 Hz

- All equipped machines, regardless of model, can run on 100v or 220v with a 15 amp outlet. The plug type for 110v is NEMA 5-15P (for wall receptacle NEMA 5-15R).

For more information, see **“Electrical Safety” on page 6.**


5. Connecting the Laser to Your Computer

You are now ready to connect your computer to the laser. The following connections can be used:

1. **USB only connection:** You can use the USB port for connecting to the Software Suite, however, multiple laser systems cannot be operated from a single computer through a USB connection.
2. **Ethernet only connection:** With an Ethernet connection you can print from the Software Suite to multiple machines at once.
3. **Wireless connection:** To connect to the laser via wireless connection, boot up the laser and follow the instructions **“6. Power on the Laser” on page 23.**

USB Connection

A USB cable is included in the accessory kit. The USB port is located on the right-hand side of the machine. USB cables have different connectors on each end. The USB connection will behave similarly to an Ethernet cable when communicating with the laser. Both the computer and machine should recognize the USB without any need to reboot.



Ethernet Connection


The Ethernet Port is a standard 1000Base-T connection, and is backwards compatible with 100 and 10Base-T. Your Epilog Laser has all of the versatility of a network capable peripheral. As such, there are many different ways that the laser can be connected to a computer or a network. Connect the Ethernet cable (included in the accessories kit) to the Ethernet port, located on the right-hand side of the machine. Plug the cable into the Ethernet port on the laser, then plug the other end into the Ethernet port on your

SECTION 2: GETTING STARTED

computer.

6. Power on the Laser

1. When you boot up the Fusion Ascent for the first time, you will need to set up a few settings in the unboxing wizard to get started. On the first screen, select your preferred language and then click the next arrow.



2. Confirm that your laser's exhaust system has been set up by pressing the green next arrow.



SECTION 2: GETTING STARTED

- Follow the steps on the screen to run your first engraving using the anodized aluminum piece included in your Training Suite Kit. Press the green next arrow.



- At the Job Menu, select the job "Epilog Demo" and then press the Go/Stop button at the machine to begin running your first job. The machine will automatically focus to the piece of anodized aluminum and then engrave it.



- Once the engraving is complete, it's time to connect your Fusion Ascent to your computer. You can connect via Ethernet, USB, or Wireless connection in the steps on the following pages.
 - For Ethernet Setup, see **"Ethernet Setup" on page 25.**
 - For USB Setup, see **"USB Cable Setup" on page 26.**
 - For Wireless Setup, see **"Wireless Setup" on page 27.**

SECTION 2: GETTING STARTED


7. Set the IP Address

Ethernet Setup

1. A screen will appear asking how you would like to connect your laser. Select **"Ethernet"**.



2. Select the text in the IP Address box and type in whichever IP Address you prefer to use. Most Epilog users will use the IP Address of **192.168.3.4** which is what we use in this manual. Press the **Green** arrow to complete the setup.



3. This will be the IP Address you use in the Job Manager when you set up your machine. For more information, see **"Using the Epilog Job Manager" on page 33.**


SECTION 2: GETTING STARTED

USB Cable Setup

1. A screen will appear asking how you would like to connect your laser. Select “**USB**”.



2. Under “**IP Address**” the IP Address will be **169.254.7.2**. Press the **Green** arrow to complete the setup.



3. This will be the IP Address you use in the Job Manager when you set up your machine. For more information, see “**Using the Epilog Job Manager**” on page 33.


SECTION 2: GETTING STARTED

Wireless Setup

1. A screen will appear asking how you would like to connect your laser. Select **“Wireless”**.




2. On the next screen, select your wireless network from the list and press the green next arrow. Select “WPA2 Personal” if you are connecting to a secured network. Select Open if you are connecting to an open network. Tap the box under “Security Key” and type in your password. Then press the green next arrow to connect.



Note: You must select the same network that your computer is connected to.


SECTION 2: GETTING STARTED

3. Select “Obtain an IP Address Automatically” and click the green arrow to finish setup. Once connected, your screen will show a green check mark. Press the green next arrow.



8. Install the Software Suite & Set Up Your Laser

Follow the instructions for the remainder of the setup. For detailed instructions on installing the Software Suite, see **“How to Install the Epilog Software Suite” on page 35**. For detailed instructions on installing your laser in the Job Manager, see **“SECTION 4: THE JOB MANAGER” on page 33**.



SECTION 2: GETTING STARTED

9. Sign Up for Driver Updates and Register Your System

Go to www.epiloglaser.com/register and register your system. You can also sign up for our weekly e-newsletter, quarterly customer printed newsletter, and sign up for driver update notifications.


For information on installing and using the Epilog Dashboard software, visit our training site:
support.epiloglaser.com



SECTION 3: CONTROL PANEL

Display

The display shows valuable information associated with the highlighted Functional Menu items. We will explain the different information that will be displayed as we go through the description of each menu item.



Status Indicator

In the bottom left corner of the screen you will see text displaying the current status of the machine.

- **Homing:** This indicates the machine is still powering on. None of the functions are available until powering on is completed.
- **Idle:** The machine is inactive and ready to run or resume a job.
- **Running:** A job is in progress when this is displayed.
- **Parking:** The axis is returning to Home position.
- **Jogging:** Jog mode is active.

Symbols



Go/Stop Button

Press the Go/Stop button to start and pause a job.

SECTION 3: CONTROL PANEL

- Pressing the Go/Stop button during a running job will stop the lens carriage and the laser beam will be shut off. If the Go/Stop button is pressed during raster engraving mode, the lens carriage will pause on either the far left or far right of the engraving line that is in process. If the Go/Stop button is pressed while in vector cutting mode, the lens carriage will stop at the end of a line segment or at the next line node location.
- Once the lens carriage has stopped, you can open the door to examine the job. By closing the door and pressing the Go/Stop button, the job will commence where it left off. If the item being engraved/cut has not been moved, the engraving/cutting registration will not be affected.
-  **Note:** Opening the door on the laser during engraving or cutting will stop the laser from firing; however, the lens carriage will continue to move. It is important to stop the job before you open the door to ensure the engraving/cutting is completed.
- If you press the Go/Stop button while in vector mode it may take some time for the system to actually stop. The system needs to get to the next node in a vector before it can stop.

LED Status

The ring around the Go/Stop button will change certain colors depending on the machine's status.

- **White:** The machine is booting.
- **Purple:** The machine is waiting for the touch screen configuration to load.
- **Multi-colored:** The machine is Homing.
- **Alternating Light Blue to Green:** Machine is Idle and ready to run a job.
- **Green:** Machine is actively running or tracing a job.
- **Red:** A drive has failed. The number of flashes determines the drive number that failed. If more than one drive has failed, it flashes for the first sequential drive.
 - 1 - X Axis
 - 2 - Y Left Axis
 - 3 - Y Right Axis


Reset Key

- Pressing the Reset key will move the carriage back to its Home Position. Press the Reset key after you have moved the carriage when in Jog mode.
- You may also press this key if you want to start a job over after pausing it with the Go/Stop button. Reset does not erase the job from the laser systems memory; rather it will stop the engraving job in process and send the carriage back to the Home Position.



Focus

The Focus function allows you to manually set the table to the correct height for engraving while using the Focus Gauge. With Focus highlighted, use the Joystick to move the table up or down. The display will show a digital readout of the table position. Press once to enable the Focus feature and the icon will turn green. Press again to exit this feature.



SECTION 3: CONTROL PANEL

Pointer

The Pointer key is a toggle switch that turns the laser system's Red Dot Pointer on and off. **For more information visit "Red Dot Pointer" on page 46.**



Jog

The Jog function allows you to move the laser head around the table with the use of the Joystick. To make it easier to use, turn on the Red Dot Pointer for a visual indicator of where the carriage is moving. The carriage can be moved in X, Y or diagonally. The display will show a digital readout of the carriage position. This function is useful for bringing the focus gauge to any object on the table to ensure it's focused properly. **For more information see "Auto Focus vs Manual Focus" on page 45.**




Trace

The Trace function allows you to preview the placement of your artwork on your work piece before you run the job. To use, turn on the Red Dot Pointer, select your job from the Job Menu, and press the Trace key. The laser head will begin tracing the entire outline of your job repeatedly. To stop tracing, press the Trace key again.



Job Menu




- The Job Menu allows you to scroll through the jobs in your laser system. You will be able to see a list of jobs that have been sent to the laser. The job name displayed is the same as the file name that you printed to the laser.
- When the job you want has been selected, it will be highlighted in blue. Press the Go/Stop button to start the job.

SECTION 3: CONTROL PANEL

- After the job starts, the job's settings and a timer will be activated and will be shown at the bottom of the display.
- Saved jobs will always be visible at the bottom of the list with a save icon next to the job name.
-  Pressing and holding down your finger on a job will pull up the job's settings, allowing you to view the Speed, Power, and Resolution or Frequency. A save button will also be visible in the upper right corner that allows you to save the job permanently to the laser.

Editing Job Settings at the Machine

1. Print a job to the Ascent.
2. Long press on the job and the Speed and Power values will come up.
3. Press the job again and the Speed and Power boxes will come up at the bottom of the screen.
4. Highlight the one you want to change and another dialog box will come up at the bottom of the screen.
5. Delete the number in the box and then insert the new value(s).
6. Press the Save icon to save the change. If you exit this screen without pressing the Save icon, your changes will not be saved.



Speed

This icon indicates the speed settings on the selected job. It ranges from 1-100%.



Power

This icon indicates the power settings on the selected job. It ranges from 1-100%.



DPI

This icon indicates the resolution settings on the selected job. It ranges from 75-1200.



Frequency

This icon indicates the frequency settings on the selected job. It ranges from 1-100%.

SECTION 3: CONTROL PANEL


Delete Button



The Delete Button will permanently erase jobs from the Job Menu. To delete a job, select the job in the Job Menu, and then select the Delete Button. A dialog will pop up to confirm that you want to delete the file. Select “Yes” and the file will be removed from the Job Menu.



Note: If you have marked a job as “Saved” and delete the file, it will still be erased from the Job Menu.



Settings Menu

The Settings menu has 8 sub-menus.

Home

This menu allows you to set an offset to the Home position.

Tutorial

This menu allows you to set up your machine. It is the same process as when you set up your laser for the first time, including a demo job to test the machine.

Focus

This menu includes options to calibrate the table, CO2 or fiber focus, or the plunger.

Laser

This menu allows you to fine-tune your laser's settings.

Backup

This option allows you to backup and restore the machine's factory settings.

Network


This menu allows you to set up your machine's network settings via Ethernet, Wifi or USB.

Alignment

This menu is used for aligning the laser of the machine.

Program

This menu is used for updating the peripherals of the machine.



SECTION 3: CONTROL PANEL

Configuration Menu

The Config menu has three sub-menus, System, Network, and About Machine.

System

Once selected, the System Settings display detailed information about the machine. These are factory settings that should not be changed unless instructed by Epilog Technical Support.

Network

Once selected, the Network Settings allow you to change the IP Address and the Netmask. The IP Address on this screen should match the IP Address you have assigned your machine in the Job Manager. If you have multiple machines, each one will need its own IP Address. For more information, see **“7. Set the IP Address” on page 25**.

About Machine

Once selected, this section displays info about your laser's firmware version, laser power, and Serial Number.

Park Axis

Pressing Park Axis returns the Laser to the Home Position.

Home Axis

Pressing Home Axis repeats the Homing process that happens when the machine powers on.

Home Table


Home Table resets the table height to its Home Position.



SECTION 3: CONTROL PANEL

Advanced Settings

Access the Advanced Settings Menu by first going to the Settings Menu, then long pressing the text “Settings” at the top of the screen.



In this menu you have options for calibrating various parts of the machine, including the Joystick, Cameras and Auto Focus. Each option provides step by step instructions for each process.

For more information about Camera Calibration, **see “Camera Calibration” on page 82.**

For more information about Auto Focus Calibration, **see “Calibrating the Auto Focus” on page 79.**

SECTION 3: CONTROL PANEL

Jog Menu



Access the Jog Menu by pressing the Jog key, which will turn green when active. The Jog Menu allows you to adjust the current X and Y axis positions of the laser head. You may change the current position of the laser head either using the Joystick, or by entering precise coordinates under “Move To”.

Locking Coordinates



The X and Y coordinates may be locked and unlocked to help you fine-tune the laser head's position. Tap the lock icons to lock or unlock the X and Y coordinates. When only the X coordinate is locked, the joystick will only move the laser head in the Y direction (toward the front or back of the machine). When only the Y coordinate is locked, the joystick will only move the laser head in the X direction (left or right). If both the X and Y coordinates are locked, the laser head will not move until they are unlocked.

Move To

Enter X and Y coordinates to move the laser to a specific location on the table.

Centering Point

Pressing this button tells the laser where you want the center of your artwork to be. While jogging the laser head across the table, use the red dot pointer to help identify the center point of your engraving. The Centering Point feature is used with Center-Engraving enabled jobs. To return to the Centering Point you have previously set, long-press the Centering Point button and the laser head will return to that point.



Park Axis

Park Axis returns the laser head to the default home position in the upper left corner of the table. To change the default park position, **see “Setting Park Position / Resetting Park Position” on page 40.**

Home Axis

The Home Axis button homes the laser head and then returns it back to the home position, the default every time you turn on the machine.

Nudge

The Nudge arrows allow you to fine-tune the position of the laser down to a thousandth of an inch. To change the increments you want to nudge the laser's position, click the text box under “Nudge” and enter an amount.

Auto Focus



The Auto Focus button is in the center of the Nudge arrows. When you have jogged the lens carriage above your material, press the Auto Focus button to use the plunger Auto Focus. The table will rise until the material touches the plunger, then set the table to the correct height. Your job should now be in focus.



SECTION 3: CONTROL PANEL



Note: For more information about Auto Focus, see “Auto Focus” on page 45.

Focus Menu



To access the Focus Menu press the Focus key, which turns green when active. The Focus Menu is used for raising or lowering the table level to focus the laser precisely to your engraving or cutting material using the Focus Gauge. The height of the table is adjustable by either using the joystick, or using the Nudge arrows. Once you are finished using the Focus Menu, press the Focus key again to return to the main Job menu.

Move To

Enter an amount to focus the table to the laser at a specific height.

Nudge


The nudge arrows allow you to fine-tune the position of the laser down to a thousandth of an inch. To change the increments you want to nudge the laser’s position, click the text box under “Nudge” and enter an amount.

Auto Focus

When you have jogged the lens carriage above your material, press the Auto Focus button to use the plunger Auto Focus. The table will rise until the material touches the plunger, then set the table to the correct height. Your job should now be in focus.

Settings

Pressing the gear icon on the Focus menu allows you to save “Thickness Presets” which can be useful for items you work with regularly that have a consistent thickness. Simply type in the table height you wish to use and save the presets by pressing the save icon. Now when you press the numbers 1, 2, or 3 on the focus menu, and then press “Move To”, your machine will adjust the table to that height.



SECTION 3: CONTROL PANEL

Setting Park Position / Resetting Park Position


1. To set a new Park Position, press the Settings gear button in the upper right corner.




2. Under the Settings menu, press the wrench and gear icon in the bottom left corner to open the Config Settings Menu.



3. Press **“System”** to expand the menu.



4. Scroll down to **“Park Position”** and press it to open up the submenu.



- 5.

SECTION 3: CONTROL PANEL


6. Tap the current number value below Park Position to change it to the X & Y coordinates of your choice. Press “**Ok**” to save the new coordinates.



7. To reset Park Position to its **default position**, follow the previous steps and change both the X & Y value to “1”.

Enabling/Disabling Wireless

1. To enable or disable the Wireless connection option on your machine, first go to the **Settings Menu**.



2. Under the Settings Menu, select “**Network**”.




3. Press the minus symbol to turn off wireless, and the plus symbol to turn it back on.

SECTION 3: CONTROL PANEL

4. **Note:** If you are already set up with an ethernet connection and the Network Menu does not display, press the “ethernet” icon to

return to the Network Menu first.



Joystick

The Joystick feature is used in Jog mode and Focus mode. The Joystick is progressive and touch sensitive and provides a continuously variable range of adjustments. It is sensitive to the degree of tilt that is being applied. The more you tilt the Joystick, the bigger your impact on the function you are using.

Job Storage

The Fusion Ascent has 1 GB of permanent storage. While powered on, the machine will store any and all jobs sent until there is no free memory left. This feature allows you to save your most run jobs right at the laser without needing to first print them from the computer.

To save a job, press and hold down on a job in the Job Menu until it pulls up the job's settings. Select the save button in the upper right corner and the job will save permanently to the laser until manually deleted. If you do not save a job, it will be deleted upon powering down the machine.

SECTION 4: SYSTEM FEATURES

IRIS™ Camera Positioning System



The Fusion Ascent includes the IRIS™ Camera Positioning System which allows you to precisely place your artwork on screen in seconds. The overhead camera(s) provide a live picture of the working area for accurate artwork placement, and a camera at the lens allows the system to find preprinted registration marks. Your machine will either have 1 or 2 overhead cameras, depending on your machine's model.

Using the IRIS™ Camera

The live preview of your projects can be viewed within the Epilog Dashboard under the Preview tab. The IRIS™ Camera Positioning System will provide the most accurate results when:

1. The piece being cut or engraved is placed **directly underneath the camera(s)**, and
2. The table level is **focused to the piece**. If the piece is not in focus on the table, the artwork may not be aligned properly in the live preview on the Dashboard.

The camera(s) may also be calibrated for improved accuracy. **For more information, see “APPENDIX C: SYSTEM CALIBRATION” on page 79.**



Note: The top door of the machine must be completely shut to use the live preview in the Epilog Dashboard.

Touch Screen

The Fusion Ascent is controlled by a 7” capacitive resolution touch screen. This feature allows you to select between jobs, change settings, and more. For more information on how to use the touch screen, see **“SECTION 3: CONTROL PANEL” on page 31.**



SECTION 4: SYSTEM FEATURES

Air Assist



The Air Assist feature on the Fusion Pro, Fusion Edge, and Fusion Maker Laser is used to keep combustible gases away from the cutting surface and to reduce flare-ups of more flammable materials as you cut through it, such as wood and acrylic.

The Air Assist directs a constant stream of compressed air across the material surface at the point of burn removing the heat and combustible gases from the work surface. The constant air stream helps reduce charring and scorching associated with materials, such as wood, rubber, and acrylic.

The Fusion Ascent systems have cone air assist. This feature directs air through the cone shaped part of the assembly, and permanently remains on while running any job to help keep the lenses clean.

Air Assist should always be activated during vector cutting operations to reduce the risk of fire! For more information, see **“Laser Safety” on page 5**.

The Fusion Ascent systems have been pre-plumbed for Air Assist so that all you need to do is to attach a small compressor pump to the back of the machine. The pump can either be purchased through your Epilog representative or you can connect your existing compressed air supply to the 5/16 inch (8 mm) receptacle at the back of the machine (30 PSI max). **See “Air Assist Pump” on page 21 for more information.**

SECTION 4: SYSTEM FEATURES

Auto Focus vs Manual Focus

In order to engrave or cut a crisp, clean image, your material must be the correct distance from the bottom of the focus lens. Setting the distance from the bottom of the focus lens to the top of your material is the process of focusing, and is accomplished by placing your material on the table and moving the table up or down.

Auto Focus

Activating the Auto Focus can be done on your computer in the Auto Focus box in the Dashboard. The default setting is “Off”, however you may also choose between Thickness mode or Plunger mode.

Thickness Mode: If you select this mode, you must enter the thickness of your object in the Processes Section under each individual process. If all processes in your job need to be focused at the same level, it may save you time to enter the thickness before splitting the job into multiple processes.]



Please note: The material thickness is still required when using the Vector Cutting Table. If a thickness is not specified the system will Auto Focus to the top of the grid, not to the top of your material. To enter the material thickness of the object you will be engraving/marketing/cutting use a pair of calipers for an accurate measurement and enter this value in the “Thickness” box in the driver.



WARNING: Do not use the Auto Focus plunger to focus directly on the Vector Cutting Table or Slat Table.

For more information on dividing jobs, thickness, or the auto focus plunger, visit our training site:

support.epiloglaser.com



SECTION 4: SYSTEM FEATURES

Manual Focus

These photos show the Manual Focus Gauge that is used to determine the correct distance from the focus lens to the top of your material. This gauge is included with your system.

Place the object to be cut or engraved anywhere on the table of the machine. Select the **Jog** button on the touch screen and use the **Joystick** to bring the focus gauge to the object. Deselect the Jog button, then select the **Focus** button on the touch screen and move the **Joystick** up or down to move the table appropriately until your material just touches the bottom of the gauge. The speed at which the table rises or lowers can be controlled by applying varying pressure upwards or downwards on the **Joystick**.

You may also fine-tune the table height in the Focus Menu. Once the focus position has been established, flip the gauge back up into its locked position. Press the Focus button to leave the menu and then press the **Reset** key to bring the laser head back to its Home Position.



WARNING: Do not leave the Manual Focus Gauge down when running jobs or when using Auto Focus!

If your material has a taper or curve, pick an intermediate point between the highest and lowest points being engraved and focus on that point. In general, the area of the material being engraved needs to be relatively flat. If the area being engraved differs in height by more than about an .125" (3 mm), the image will begin to look "fuzzy" or out of focus.



WARNING: If you are using Auto Focus or the Manual Focus Gauge and you know there is not enough clearance between the lens carriage and your material, you will need to lower the table before you insert your material and start the job. To lower the table, use the Joystick while in the Focus menu to lower the table enough to accommodate your part.

Key Switch

The Key Switch feature is used to power the Fusion Ascent on and off, and also allows you to lock out any unauthorized users by powering down the machine and removing the key.



Red Dot Pointer

The Red Dot Pointer is a visible laser beam that runs in the same line as the invisible CO2 laser beam. It is useful for showing the location of the laser head when using Jog or Focus mode.

SECTION 4: SYSTEM FEATURES

Emergency Stop Button

On the top of all Fusion Ascent models, you will see a large, red Emergency Stop Button. If there is an emergency, such as a fire, immediately press the Emergency Stop Button. The laser carriage will immediately stop and the system will shut down.

To reset the system on the Fusion Ascent, you must **turn off the system** using the Key Switch, then twist the **Emergency Stop Button** clockwise to release the system, then **turn on the laser**.



If your laser ever stops running and you can't turn it on, check to see if the Emergency Stop Button has been pressed by accident.



Vector Cutting Table

On all Fusion Ascent models, the Vector Cutting Table is used for both standard engraving jobs, as well as vector jobs where the laser penetrates all the way through the material being cut. The Vector Cutting Table lifts your work material away from the crumb trays and allows the laser beam to penetrate all the way through the material without reflecting back up onto the backside of your work.



Exhaust Plenum

The Fusion Ascent incorporates an Exhaust Plenum. The exhaust fan moves air from the front towards the rear of your machine and out the exhaust plenum. This air removes combustible gases and smoke through the exhaust plenum. This air removes combustible gases and smoke thorough the exhaust plenum.

SECTION 4: SYSTEM FEATURES

Status Light

The Fusion Ascent has a status light that lights up while the machine is running a job. This is useful to help indicate when a job has been completed, as the light will turn off as soon as it's finished.

In Class 2 mode, the red indicator light indicates that the laser is in a state of readiness and could potentially fire. When all interlocked doors are closed, the red indicator light will be on. With any of the interlocked doors open, the light will go off. In Class 4 mode, the red indicator light will be on whenever the top door is closed, regardless of whether the pass-through doors are open.



SECTION 5: SYSTEM MAINTENANCE

Reduce Fire Risk with a Clean Laser



Cleaning your machine is an excellent way to prevent fire with the laser. A buildup of cutting and engraving residue and debris is dangerous and can create a fire hazard in its own right. Keep your laser system clean and free of debris. Regularly remove clean any small pieces that have fallen through the cutting grid. **For more information on fire safety, see “FIRE WARNING” on page 1.**

As with all equipment, preventive maintenance is an important part of owning your Epilog Laser system. A laser system by its very nature creates debris and residue on every job. Over time, these by products can build up and start to clog the components of your system. Like anything, the build up can be almost imperceptible and easy to ignore. Since it 's guaranteed that these by products will build up over time, it's worth spending just a few minutes each week keeping your system clean. To extend the life of your investment, follow these simple guidelines outlined below.

2x WEEKLY	Why Do I need to Clean This?	Materials Needed	Instructions
Optics	If smoke, resin, or other contaminants are allowed to accumulate too heavily, they will reduce the available laser power and will cause damage to the optics and/or mirror.	Cotton swab, optics cleaning fluid.	1. Use a cotton swab that is soaked with optics cleaning fluid. 2. Gently swab the optics to remove dust and debris. 3. Prepare a fresh swab and clean the surface with a gentle zigzag motion across it.
Auto Focus Plunger	Removing residue helps ensure precise focusing.	Cotton swab or soft cloth, mild household cleaner or isopropyl alcohol.	Use a soft cotton cloth and mild household cleaner or isopropyl alcohol to gently wipe the Auto Focus plunger until it is clean.
Crumb Tray	This will reduce any fire hazards by removing debris that has fallen through the table.	Small brush or vacuum cleaner.	Remove the Cutting Table and clean out the table tray using a small brush or vacuum cleaner.
MONTHLY	Why Do I need to Clean This?	Materials Needed	Instructions
Under the Cutting Table	This will reduce any fire hazards by removing debris that has fallen through the table.	Small brush or vacuum cleaner.	Remove the Cutting Table and clean out the table tray using a small brush or vacuum cleaner.
Bearing Rails	Proper cleaning ensures bearings perform at their best.	Cotton swab or soft cloth, mild household cleaner or isopropyl alcohol.	Using the cloth or swab with liquid, clean all of the bearing tracks.

SECTION 5: SYSTEM MAINTENANCE

3 MONTHS		Why Do I need to Clean This?	Materials Needed	Instructions
Exhaust		Cleaning the exhaust system removes built-up debris and reduces fire hazards.	Wire Brush.	Make sure the exhaust blower you are using receives proper maintenance. Periodically clean the exhaust blower and duct system to remove built-up debris.
Interior Work Space		This keeps corrosive dust and debris from building up on interior surfaces.	Soft cloth and mild household cleaner or isopropyl alcohol.	Use the soft cloth to wipe all surfaces that are exposed to dust and debris.
12 MONTHS		Why Do I need to Clean This?	Materials Needed	Instructions
Overall Machine		Preventative maintenance.		Book technician for preventative maintenance and service

SECTION 5: SYSTEM MAINTENANCE

Cleaning the Optics on the Fusion Ascent

Cleaning the Lens on the Fusion Ascent

The focus lens is contained within the lens assembly.

1. Remove the cover of the lens assembly by pulling from the front handle to reveal the inside. The cover is held in place with locating pins and magnets.




SECTION 5: SYSTEM MAINTENANCE

2. Inside you will see the blue lens piece. Remove it from the lens assembly by carefully pulling it out by the handle. The lens is keyed so that it only goes in one way. It is held in place with magnets.



3. To clean the lens, use a high-quality cotton swab moistened with the optics cleaner supplied in the accessory kit. Please read the label on the bottle carefully.



SECTION 5: SYSTEM MAINTENANCE

4. Allow the optics to dry, then slide the lens back into the lens assembly, ensuring the handle is facing outward.




5. Put the magnetic plate back onto the front of the lens assembly, ensuring the locating pins line up with the corresponding holes.

SECTION 5: SYSTEM MAINTENANCE

Cleaning the Mirror on the Fusion Ascent

1. The mirror is located on the front side of the assembly and also has a simple cleaning process. Start by removing the magnetic cover on the front of the assembly by pulling from the front handle to reveal the inside.




2. Next, twist the knob on the top right side of the assembly counterclockwise to loosen the mirror, preparing it for removal.




SECTION 5: SYSTEM MAINTENANCE

3. Now remove the mirror from the assembly by sliding it out towards the front of the machine.



4. To clean the mirror, use a high-quality cotton swab moistened with the optics cleaner supplied in the accessory kit. Please read the label on the bottle carefully.



5. After the mirror has been cleaned and is completely dry, place it back into the assembly with the mirror angled down towards the table. Tighten the knob that secures it, and close the small door on the back of the assembly.

If you run out of the cleaner supplied by Epilog, Reagent or laboratory grade Alcohol can be substituted. Also, if “Golden Grain” or “Everclear” are available in your area these are also good substitutes for the optical cleaning solution.



Note: Never use Isopropyl Alcohol or Hardware grade Acetone, they contain impurities which can damage the optics in your machine.

Wet the swab thoroughly with the solvent, and then blot it against a piece of cotton so that it is no longer soaking-wet. Then daub the lens gently, rotating the swab after each daub to expose clean cotton to the surface until the optic is free of visible contamination. At that point, prepare a fresh swab and clean

SECTION 5: SYSTEM MAINTENANCE

the surface with a gentle zigzag motion across it. Avoid any hard “scrubbing” of the surface, especially while there are visible particles on it, and try not to use repetitive circular motions. When you are done, be careful to remove any cotton threads that may have snagged on the mountings.

Cleaning the Exhaust Plenum

Make sure the exhaust blower you are using receives proper service. Periodically clean the exhaust blower and duct system to remove built-up debris. If you detect odor while engraving, or if the smoke in the cabinet is visible in the area of the lens carriage, inspect the exhaust system. Check for loose or broken pipe/hose connections, or obstructions. The following photos show where to clean the duct work of your machine. You should also occasionally check your exhaust blower and the connected duct work.

Cleaning the Vents

Clean the vents from the inside of the machine. It is best to use a flexible or wire brush that can access the inside of the vent.



Cleaning the Exhaust Plenum

In addition to cleaning the inside of the machine, you should occasionally clean the exhaust plenum on the back of the system. The exhaust plenum can be completely removed from the Fusion Pro by unscrewing the mounted screws on the back of the machine.

SECTION 5: SYSTEM MAINTENANCE

Laser Tube

The laser tube used in your system does have a maximum service life, and there is very little maintenance that is required. At some point in the life of the laser you will need to replace it for gas recharge, electrical repair or mechanical repair. Replacing laser tubes is common practice and Epilog has made the process of changing tubes extremely easy for users to perform with a minimum amount of effort. The laser tubes can be refurbished and are available on an exchange basis by contacting Epilog technical support.

Ensure that all of the laser cooling fans are properly working at all times. The fans keep the laser tube cool and prevent it from overheating. An overheated laser tube will produce erratic output and may fail completely.

If the laser system is in a dirty or dusty environment, make sure that the cooling fins on the laser tube are kept free of dust buildup. Use compressed air to blow the dust and debris off of the laser tube fins. Be sure that the system is unplugged before performing any maintenance on the machine!

SECTION 6: SPECIFICATIONS

Fusion Ascent 12/24 Laser Technical Specifications

	Fusion Ascent 12 (CO2)	Fusion Ascent 12 (Fiber)	Fusion Ascent 24 (CO2)	Fusion Ascent 24 (Fiber)
Maximum Engraving Area	24" x 12" (610 x 305 mm)		24" x 24" (610 x 610 mm)	
Max Material Thickness	7" (178 mm)			
Max Table Weight	Static table weight: 40 lbs (18.1 kg) Lifting table weight: 25 lbs (11.4 kg)			
Laser Source Wattages	30, 40, or 60 watt, CO2, air-cooled, metal/ceramic tube, 10.6 micrometers.	30 watt Fiber MOPA, air-cooled, includes collimator, 1064nm. Beam quality: M2 <1.1	40, 60 or 80 watt, CO2, air-cooled, metal/ceramic tube, 10.6 micrometers.	60 watt Fiber MOPA, air-cooled, includes collimator, 1064nm. Beam quality: M2 <1.1
Standard Features	Radiance High Definition Optics (CO2), Air Assist, Red Dot Pointer, relocatable Home Position, LED lighting, integrated floor stand, brushless servo motors, Super-Silent Cooling Fans, Joystick controls, removable exhaust plenum.			
Intelligent Memory Buffer	Multiple files up to 1GB. Engrave any file size.			
Operating Modes	Optimized Raster, Vector & Combined modes.			
Motion Control System	High-speed, continuous-loop, brushless DC servo motors using rotary encoding technology for precise positioning.			
X-axis Bearings	Ground & polished stainless steel, Teflon-coated, self-lubricating bearings.			
Belts	Advanced B-style double-wide Kevlar precision drive belts.			
Resolution	Fully-flexible and user-controlled from 75 to 1200 DPI.			
Speed and Power Control (engraving depth)	3048 mm/s (120 IPS) with 5G acceleration. Computer-controlled in .001 increments up to 100%. Color mapping feature links Speed, Power, Frequency, and Raster/Vector mode.			
Print Interface	10Base-T Ethernet, or USB. Compatible with Windows or Mac*. Wireless.			
Size (W x D x H)	41.76" x 25.9" x 20.15" (1060,7 mm x 657,9 mm x 511,8 mm)		41.76" x 38.47"x 20.15" (1060,7 mm x 977,1 mm x 511,8mm)	
Weight	147 pounds (66 kg)		175 lbs (79 kg)	
Electrical Requirements	See "Electrical Safety" on page 6.			
Exhaust Requirements	350-400 CFM (595-680 m3/hr) external exhaust to the outside or internal filtration unit required.			
Exhaust Ports	One output Port 4" (102 mm) diameter.			
Laser System Classification	Class 2 Laser Product - 1 mW CW Maximum 600-700 nm.			

* The Fusion Ascent machines are compatible with Mac computers and tablets, using the web app.

Technical specifications and product configurations subject to change without notice.

SECTION 6: SPECIFICATIONS

Fusion Ascent 36 Laser Technical Specifications

Fusion Ascent 36 (CO2)	
Maximum Engraving Area	36" x 24" (914 x 610 mm)
Max Material Thickness	7" (178 mm)
Max Table Weight	Static table weight: 40 lbs (18.1 kg) Lifting table weight: 25 lbs (11.4 kg)
Laser Source Wattages	40, 60 or 80 watt, CO2, air-cooled, metal/ceramic tube, 10.6 micrometers.
Standard Features	Radiance High Definition Optics (CO2), Air Assist, Red Dot Pointer, relocatable Home Position, LED lighting, integrated floor stand, brushless servo motors, Super-Silent Cooling Fans, Joystick controls, removable exhaust plenum.
Intelligent Memory Buffer	Multiple files up to 1GB. Engrave any file size.
Operating Modes	Optimized Raster, Vector & Combined modes.
Motion Control System	High-speed, continuous-loop, brushless DC servo motors using rotary encoding technology for precise positioning.
X-axis Bearings	Ground & polished stainless steel, Teflon-coated, self-lubricating bearings.
Belts	Advanced B-style double-wide Kevlar precision drive belts.
Resolution	Fully-flexible and user-controlled from 75 to 1200 DPI.
Speed and Power Control (engraving depth)	120 IPS (3.05m/s) with 5G acceleration. Computer-controlled in .001 increments up to 100%. Color mapping feature links Speed, Power, Frequency, and Raster/Vector mode.
Print Interface	10Base-T Ethernet, or USB. Compatible with Windows or Mac*. Wireless.
Size (W x D x H)	53.76"x38.47"x20.15" (1365,5 mm x 977,1 mm x 511,8mm)
Weight	212 lbs (96 kg)
Electrical Requirements	See "Electrical Safety" on page 6.
Exhaust Requirements	350-400 CFM (595-680 m3/hr) external exhaust to the outside or internal filtration unit required.
Exhaust Ports	One output Port 4" (102 mm) diameter.
Laser System Classification	Class 2 Laser Product - 1 mW CW Maximum 600-700 nm.

*The Fusion Ascent machines are now compatible with Mac computers and tablets, using the Epilog Pulse web app.

Technical specifications and product configurations subject to change without notice.

SECTION 6: SPECIFICATIONS

Compatibility

Your Epilog Laser has been designed as an “open architecture” product that can be run from almost any Windows based software.

Recommended PC

For Optimum Computer Performance

Investing in a new computer is a great way to make sure you’re getting the most out of your new laser equipment. Why? Because today’s software (CorelDraw for instance) requires a lot of computer processing speed and memory to function properly. A good computer won’t make a big difference in how your laser runs, but when compared to a slow computer it will save untold amounts of time and frustration setting up the artwork that you “print” to the laser. Many users do not purchase new computers for use with their new laser because their current computers are perfectly adequate. There’s no magical cut-off that makes a computer too slow. If you’re comfortable with the performance and speed of your current computer, there’s probably no reason to purchase another one. The following recommendations are just advice to consider if a new computer is necessary.

A new computer doesn’t have to be expensive to work great. The minimum requirements are included in just about any new laptop or desktop that can be purchased.

Operating System

Windows 10 will work with the Fusion Ascent and the Epilog Software Suite. Operating system should have all system updates before installation of the Epilog Software Suite. The Fusion Ascent machines are also now compatible with Mac computers and tablets, using the Epilog Pulse web app.

RAM – Random Access Memory

4GB RAM is the minimum that is required, however we recommend 8GB or more if possible. RAM is like short-term memory. It’s fast and readily available for the computer to access and makes time consuming tasks go much quicker if you have lots of it. Having more than 4GB of RAM is nice if you demand a lot from your computer.

Processor Speed

A faster processor will allow you to do more tasks in less time. While it’s not necessary to purchase the fastest processor available, you’ll want adequate speed to operate your graphics program. Processor speeds are always improving, but processor speeds of about 3.0 GHz or faster are a good place to start.

Graphics Card

Your computer’s graphics card will need to support OpenGL 3.0 (or higher) or OpenGL 2.0ES (or higher) to operate the Epilog Software Suite. For example, an Intel HD 2000 or greater, nVidia GeForce 8000 series or greater, or an AMD/ATI Radeon HD2000 series or greater will be sufficient.

10/100 Network Interface Card (NIC)

All new computers have a 10/100 network connection as standard equipment. As well as allowing multiple computers to be linked together in a network, this technology also allows direct printing from the computer to the laser. Epilog supplies a network Crossover cable with each laser system that allows one computer to print to a single Epilog Laser system.

Hard Drive

This is the permanent memory in your computer. Many users feel that you can never have a large enough

SECTION 6: SPECIFICATIONS

hard drive. Luckily, most computer manufacturers put high capacity drives in new computers these days. When in doubt, buy bigger than you think you might need. It's so in-expensive that it's worth the peace of mind to have it available.

Software

Many users use Corel as their graphics software. Many other Windows software applications can also be used, although all software is different and may not be predictable, user friendly or functional. Additionally, the technical support staff at Epilog may be less familiar with software other than Corel and less able to help with questions. Consult with your Epilog distributor on software compatibility issues. Epilog does not guarantee compatibility with any software.

PhotoLaser Plus is a third-party software for converting photos to laser compatible format. This is an indispensable option for engraving photos.

Heavy Duty Surge Protector

The need for a surge protector varies greatly throughout the world. If the laser is operated anywhere that the electrical power is subject to spikes, outages, lighting, fluctuations, etc, a surge protector should be used on both the laser and the computer. A surge protector is a very cheap insurance policy against catastrophic electrical damage. A surge protector is designed to be an inexpensive device that absorbs any electrical problems before they can damage the expensive equipment (computer and laser) they are protecting.

About The CO2 Laser Source

Your Epilog CO2 laser system uses the latest in laser technology to provide a powerful tool that is simple and safe to setup and operate. The Epilog Laser can mark, engrave, and cut a variety of non-metallic materials.

The CO2 laser beam itself is invisible and operates at a wavelength of 10.6 microns. The beam is about half the diameter of a #2 pencil. Unfocused, it will just make an ugly burn, leaving lots of charred material behind. The focus lens gives the beam an hourglass shape. At the center point the energy density is concentrated, allowing the very precise and clean material removal that is characteristic of laser engraving. The center of the hourglass is the focal point.

In Class 2 mode, the laser beam path is completely enclosed within the cabinet. Please do not disassemble or modify any of the covers or windows on the machine. If at any time you notice that the laser operates with a door or window open, please contact Epilog technical support immediately.

The laser has two basic operating methods. For cutting (vector), the laser is driven along a path and the laser is left on all the time. The path could be the outline of a letter or a geometric shape like a circle. The laser will cut entirely through the material, separating the part from the background. For marking (engraving), the laser is swept across the work from left to right, and the laser is turned on and off at the correct points to produce the first line of the image. Then the carriage advances one line and the process is repeated, eventually assembling a full image.

SECTION 6: SPECIFICATIONS

Federal Communications Commission (FCC)

Notice



This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy; and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his/her own expense.

Epilog's CO2 Laser Line Specification:

Model	A	B	C	D*	E*	F*	G*	H*	J*	K*
Rated Output Power (watts)	40	30	50	60	120	75	80	100	120	200
Peak Power (watts)	100	100	150	150	350	150	150	200	240	400
Power Stability from cold (10 min)	±6%	±6%	±7%	±7%	±9%	±7%	±7%	±10%	±10%	±10%
Mode Quality (M ²)	<1.2	<1.2	<1.2	<1.2	<1.2	<1.2	<1.2	<1.2	<1.2	<1.2
Ellipticity	<1.2	<1.2	<1.2	<1.2	<1.2	<1.2	<1.2	<1.2	<1.2	<1.2
Polarization	Linear									
Beam Diameter (1/e ²)**	1.7	1.7	1.7	7	2.0	2.7	7	7	7	7
Beam Divergence (full angle)**	7.0	7.0	7.0	1.7	6.0	4.4	1.7	1.7	1.7	1.7
Rise Time (µs)	<100	<100	<100	<100	<100	<100	<100	<100	<100	<100
Energy/pulse (J) - peak power	Depends on pulse frequency and duty cycle									
Pulse Duration	Depends on pulse frequency and duty cycle									
Pulse Rate (kHz) - repetition frequency	0-100									
Center Wavelength (µm)	10.6									
Wavelength Range (µm)	10.5-10.7									
Cooling	Air									

* Measurements taken after beam correction

** Some lasers may be equipped with beam expanders, specifications are subject to change.

SECTION 7: TECHNICAL SUPPORT

Contacting Technical Support

The technical support department at Epilog is available to assist with solving problems you may encounter using your Epilog. Please review first the common problems and solutions as noted below, then if you are still in need of assistance you may contact Epilog's technical support department at the number or website listed below. Technical support is available in Golden, Colorado USA during the hours of 6 a.m. and 6 p.m. Mountain Time.



Technical Support Online: support.epiloglaser.com




Submit a Ticket

What to do prior to contacting Epilog Technical Support:

1. Have the machine serial number available.
2. Have time to work on machine. Many issues will require troubleshooting.
3. Clean your machine (especially the optics), this will solve many issues.

The machine serial number can be found on the Certification/Identification Label. This engraved plate is located on the side of the machine's cabinet. The machine's serial number can also be found at the control panel under the settings icon. The ID label shown is for the Model 19000 product.



SECTION 7: TECHNICAL SUPPORT

Frequently Asked Questions

Engraver Will Not Vector

1. Verify that the print driver is set to Vector or Combined mode.
2. Verify that the lines that you want to vector are set to .003" (0.077 mm) or less in CorelDraw, or .001" (0.025 mm) or less in Adobe Illustrator. You may also separate the desired Vector line and set it to a Vector process in the Dashboard.
3. Make sure the images are vector lines. Scanned and raster images will not vector.
4. Filled or solid images will not vector (outlines only).

Engraving Appears Lighter Than Usual

1. All mirrors and lenses need to be cleaned and inspected for damage.
2. Verify that the lens is in correct focus.
3. Verify correct Speed, Power and Frequency settings for the type of material that you are engraving.

The Exhaust Is Not Pulling Enough Air

1. Move the blower closer to the machine. The closer the two are, the better exhaust you will receive.
2. Clean your exhaust system on a regular basis, including the engraver and blower. Use a bottle-brush and a vacuum on the areas where the exhaust buildup accumulates.

The Engraving Quality is Poor/Blurry/Double Image

1. If you feel you are not getting quality you once were, this is probably a maintenance issue.
2. Clean the optics of the system.

The Laser Won't Turn On

Make sure the Emergency Stop Button on the top of the machine is not pressed in.

SECTION 7: TECHNICAL SUPPORT

IP Address is not visible in the Settings Menu of the Machine

Make sure that your Ethernet or USB cable is plugged in fully, both at the machine and your computer.

How Can I Increase the Life of my Laser System?

- **Clean your system:** Debris in the laser and on the mechanics of the system can reduce the life of parts in your system. Wipe down your system on a regular schedule to keep the mechanics clean and long lasting.
- **Clean the lenses:** Lens life is greatly increased by keeping them clean and free of debris. Get in the habit of wiping them off on a regular schedule to keep them clean and well maintained.
- **Reduce speed when running very small items:** When you run at 100% speed on a graphic with a very short stroke, the lens assembly comes up to speed and slows down extremely quickly, which can place wear on the mechanics of the laser. Slow down to 80 - 90% speed and increase the lifetime of your laser system.

How to Shorten Your Engraving/Cutting Time

- **Lower the Resolution:** How important is the highest resolution image? Processing jobs at 400 DPI vs. 600 DPI can reduce cycle times by up to 30%, and processing at 300 DPI could mean half the cycle time.
- **Reduce White Space:** Orientate the parts to minimize engraving dead space (area where head travels, but has nothing to engrave).
- **Horizontal Layout:** If an option, horizontal text will engrave faster than vertical or curved (fit text to curve) text.
- **Split by Color:** Use the Split by Color feature to save time by adjusting the order in which the objects engrave/mark.
- **Run Multiples:** If you need to engrave multiples of the same image. You'll find you have a time savings per piece.

If these do not correct your issue or your issue is not listed, please contact the Technical Support Team.

SECTION 7: TECHNICAL SUPPORT

Join Epilog Laser's Online Community

Find out the latest Epilog news, keep in touch with our customers, and stay connected through our social media channels!



Facebook page: www.facebook.com/epiloglaser



Youtube channel: www.youtube.com/epiloglaser



X: www.x.com/EpilogLaser



Instagram: www.instagram.com/epiloglaser/



Pinterest: www.pinterest.com/epiloglaser/



LinkedIn: www.linkedin.com/company/epilog



APPENDIX A: WARRANTY STATEMENT

Warranty Statement for the Fusion Ascent Laser

Epilog Corporation warrants to the original purchaser of Epilog Fusion Model 19000 that the product will be free from defects in material or workmanship when purchased, and under proper, normal use within two (2) years from the original date of purchase.

Epilog will replace or, at its option, repair the defective part(s). Normally, Epilog will supply a replacement part for the customer to replace. Once the replacement has been performed, the replaced part must be returned to Epilog. In the case where repair is required, Epilog requires that the defective part, or machine, be returned to the Epilog factory or other Epilog designated facility. Epilog will be responsible solely for the cost of repairs, including parts and labor, which are made at an authorized Epilog facility. All other costs for replacement or repair, including, but not limited to, packaging and shipping both to and from Epilog, shall be paid by the owner. A "Core" charge may be required by Epilog to insure the return of replacement and repair parts. This warranty excludes any damage from abuse (including, without limitation, incorrect voltages, power surges, fires, improper or insufficient ventilation "acts of God" or other situations out of the control of Epilog), failure to operate in accordance with instructions provided in the Owner's Manuals for the Epilog model 19000, including specific safety and operational warnings contained therein, cosmetic damage sustained in use, and damage caused by unauthorized modifications of any equipment. All warranties to original purchasers are non-transferable. The registered owner must initiate warranty claims within the warranty period.

THE ABOVE AND FOREGOING IS THE ONLY WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED; INCLUDING BUT NOT LIMITED TO ANY WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, THAT ARE MADE BY EPILOG ON MODEL 19000. ANY WARRANTIES IMPLIED BY LAW ARE HEREBY EXPRESSLY DISCLAIMED.

No oral or written information or advice given by Epilog, its dealers, its distributors, agents, officers, or employees shall create a warranty or in any way increase the scope of this warranty. Neither Epilog nor anyone else who has been involved in the creation, production, or delivery of the Epilog Fusion Models 19000 shall be liable for any direct, indirect, consequential, or incidental damages, including but not limited to damages for loss of business profits, business interruption, loss of business information, adverse health impacts, fire, and the like, arising out of the use or inability to use these products.

Epilog Corporation provides no warranties whatsoever on any software used in connection with Epilog Fusion Model 19000.

APPENDIX B: MATERIAL SETTINGS

Fusion Ascent Suggested Material Settings (CO2)					
Material	DPI/Freq.	30 watt	40 watt	60 watt	80 watt
Acrylic					
Photo Engraving	300 DPI	100s 75p	100s 70p	100s 60p	100s 50p
Text/Clipart Engraving	300 DPI	100s 75p	100s 70p	100s 60p	100s 50p
Text/Clipart Engraving	500 DPI	100s 70p	100s 65p	100s 50p	100s 40p
Cutting 1/8" (3 mm)	100 f	6s 100p	8s 100p	20s 100p	30s 100p
Cutting 1/4" (6 mm)	100 f	3s 100p	4s 100p	8s 100p	10s 100p
Cutting 3/8" (9.5 mm)	100 f		2s* 100p	4s 100p	5s 100p
Cutting 1/2" (13 mm)	100 f			1s 100p	2s 100p
Cutting Note: Adjusting the standard focus distance so it is closer to the lens by about .080" (2 mm) will produce better edge quality when cutting 1/4" (6mm) acrylic and thicker. Two passes can be used for cutting thicker materials. There are two types of acrylic: cast is better for engraving (it creates a frosted look when engraved) and extruded acrylic produces a much better flame polished edge.					
Alumamark					
Engraving	500 DPI	100s 35p	100s 30p	100s 15p	100s 10p
Anodized Aluminum					
Photos/Clipart	400 DPI	100s 65p	100s 55p	100s 35p	100s 30p
Photos/Clipart	500 DPI	100s 60p	100s 50p	100s 30p	100s 30p
Text	500 DPI	100s 70p	100s 60p	100s 40p	100s 30p
We find when engraving anodized aluminum, text appears best at 500 DPI, but photos and clipart can be engraved with great detail down to 400 DPI.					
Cork					
Engraving	500 DPI	100s 70p	100s 60p	100s 40p	100s 20p
Fleece					
Engraving	200 DPI	100s 50p	100s 40p	100s 20p	100s 15p
When engraving fabric, try changing the graphic to 80% gray and use the Jarvis dithering pattern for the best results. Every fabric you are cutting will need to have adjusted setting - find a small swatch of the fabric you can test first.					
Glass					
Engraving	500 DPI	30s 100p	40s 100p	60s 100p	70s 100p
When etching glass, try changing the graphic to 80% gray before engraving and using the Jarvis dithering pattern. You can also diffuse heat by covering the glass with a thin layer of dish soap.					
Leather					
Photo Engraving	300 DPI	100s 80p	100s 70p	100s 50p	100s 40p
Text/Clipart Engraving	500 DPI	100s 70p	100s 60p	100s 40p	100s 30p
Cutting 1/8" (3 mm)	50 f		10s 100p	20s 100p	25s 100p
Mat Board					
Cutting	50 f	25s 40p	25s 30p	30s 30p	30s 25p

APPENDIX B: MATERIAL SETTINGS

Fusion Ascent Suggested Material Settings (CO2)					
Material	DPI/Freq.	30 watt	40 watt	60 watt	80 watt
Marble					
Photo Engraving	300 DPI	100s 90p	100s 80p	100s 60p	100s 50p
Text Engraving	500 DPI	100s 80p	100s 70p	100s 50p	100s 40p
Every marble is very different for settings. Start low and increase the power with a second run if you haven't used that marble before.					
Painted Brass					
Engraving	300 DPI	100s 35p	100s 30p	100s 15p	100s 10p
Engraving	500 DPI	100s 30p	100s 25p	100s 15p	100s 10p
Plastics					
Engraving	300 DPI	100s 45p	100s 40p	100s 30p	100s 25p
These settings work well with many plastics, including plastic phones and covers. Even one color plastics can achieve a great look when engraved.					
Plastic (2 Layer Laser Engraveable)					
Engraving	300 DPI	100s 70p	100s 65p	100s 35p	100s 25p
Engraving	500 DPI	100s 60p	100s 50p	100s 30p	100s 20p
Cutting 1/16" (1.5 mm)	100 f	10s 65p	10s 55p	20s 40p	20s 25p
Stainless Steel w/ Metal marking solution					
Engraving	500 DPI	15s 100p	20s 100p	30s 100p	40s 100p
Twill					
Cutting	25 f	70s 100p	90s 100p	90s 60p	90s 50p
Wood					
Photo Engraving	500 DPI	50s 100p	60s 100p	80s 100p	90s 100p
Clipart/Text Engraving	300 DPI	40s 100p	50s 100p	90s 100p	100s 100p
Clipart/Text Engraving	500 DPI	30s 100p	40s 100p	60s 100p	80s 100p
Deep Engraving	500 DPI	20s 100p	30s 100p	50s 100p	60s 100p
Thin Veneer (Cutting)	10 f	40s 100p	40s 90p	50s 60p	50s 40p
Cutting 1/8" (3 mm)	10 f	10s 100p	15s 100p	25s 100p	30s 100p
Cutting 1/4" (6 mm)	10 f		2s 100p	4s 100p	12s 100p
Cutting 3/8" (9.5 mm)	10 f			6s 100p	8s 100p
Cutting 1/2" (12 mm)	10 f				4s 100p
When cutting wood, multiple passes may allow cutting of thicker materials. Using Color Mapping you can adjust the focus point between passes down to the center point of the cut for the best results.					

APPENDIX B: MATERIAL SETTINGS

- **These are only suggestions:** Every type of material will react differently with the laser, even from one plastic to the next. Use these settings as your starting point then adjust one variable at a time until you achieve the result you desire. Settings for any material are a matter of personal preference. Not every material that can be run at high speed should be run at high speed. A better mark can often be achieved by slowing your laser and giving the laser longer to react to your material.
- **Test your material:** If you have a small area of the material you won't be using, or an extra item, take advantage of this area to test out your settings by engraving a small square or cutting a small circle. You can fine tune your settings in these areas.
- **Similar materials use similar settings:** When you are working with a material you aren't familiar with, think about a similar material and what settings you would use with that product. Most anodized aluminums will react well with similar settings, as will most plastics.
- **When in doubt, start low:** Remember, you can always re-run your job as long as you don't move it in the machine. Let's say you're running a photograph in a one-of-a-kind wood plaque. Start with a lower power setting, look at the engraving, then run the project a second time at high speed and lower power a second time to add a little more depth if needed.
- **Run only one part of the file:** If running a job on a new material, you can always just select one piece of the engraving, like a piece of text, and run that part first to make sure your settings are perfect before running the whole file.



To print a copy of these settings to keep next to your laser, go to www.epiloglaser.com/material-settings.htm.

APPENDIX B: MATERIAL SETTINGS

Fusion Ascent Suggested Material Settings (Fiber)			
Material	DPI/Freq.	30 watt	60 watt
Aluminum (Anodized)			
Etching/Marking	800 DPI	Speed: 30% Power: 100% Frequency: 1% Focus: 0	
Polishing	800 DPI	Speed: 75% Power: 60% Frequency: 1% Focus: +.003"	
The contrast / brightness of marks achievable on the fiber laser are excellent and can often be much brighter than marks from a CO2 laser. Taking the fiber laser out of focus by +.03" - .09" broadens the beam and produces a very bright mark on anodized coating. Lower frequency and higher power settings help offset the change in focal point. Different grades of anodized & core aluminum alloy will affect how the final marks look.			
Aluminum (Bare)			
Etching/Marking	600 DPI	Speed: 20 - 25% Power: 100% Frequency: 1% Focus: -.01 to +.01"	
Engraving aluminum will result in various shades of gray, not black. Fine tuning the settings can provide a bit more contrast but the range of applicable marks is very narrow. If the application calls for a black etch, consider using an oxidizer after engraving. Oxidizers are used most commonly if the aluminum has a protective coating (urethane, clear coat, clear anodized) covering the area that is not engraved. Deep metal engraving on aluminum can be done using multiple passes. Consider deep engraving and using a black epoxy/color fill. Although the marks on aluminum are not black like they are on steel, we have no difficulty getting 2D, UID barcodes to scan and verify.			
Brass			
Etching/Marking	600 DPI	Speed: 20 - 25% Power: 100% Frequency: 1% Focus: 0	
Laserable Plastic			
Etching/Marking	600 DPI	Speed: 60% Power: 60% Frequency: 60% Focus: 0	
Stainless Steel			
Annealing	600 DPI	Speed: 5-7% Power: 100% Frequency: 1% Focus: +.06 to +.12"	
Etching/Marking	600 DPI	Speed: 15 - 20% Power: 100% Frequency: 1% Focus: 0	
Polishing	800 DPI	Speed: 75% Power: 25% Frequency: 75% Focus: 0	

APPENDIX B: MATERIAL SETTINGS

Fusion Ascent Suggested Material Settings (Fiber)			
Material	DPI/Freq.	30 watt	60 watt
Etching: Like our C02 counterparts, the slower the speed setting, the deeper the etching. However, many metal applications can be processed at higher speed settings. Again, consider the marking requirements. Annealing: To achieve an annealed mark, the focal point should be significantly away from zero. The unfocused, broader beam provides the heat to change the surface color without actually penetrating the metal. The focal point can be either closer to or away from zero. Focusing away from the material should be in the range of .060" to .090". Focusing closer to the material is generally in the range of -.070" to -.110". Both focusing methods will result in annealing of the metal. Focusing up typically results in a slight indentation of the metal. Multiple passes can darken the mark even more (no data to confirm whether multiple passes offer more permanency). Polishing: Some steel alloys are easier to polish than others. For best results, clean off the surface with alcohol prior to processing. Any leftover grease, oils or residue can affect how well the polished mark turns out. Polishing the metal where the final marks result in a bright white engraving requires finer tuning of settings, more so than the etched or annealed marks. Determine a base speed and frequency setting and adjust the power in small increments/decrements. If you are unable to get a white bright mark, increase the frequency setting and try again by adjusting only the power.			
Titanium			
Annealing	600-1200 DPI	Speed: 5-7% Power: 100% Frequency: 1% Focus: +.08 to +.110"	
Etching/Marking	600-800 DPI	Speed: 20 - 25% Power: 100% Frequency: 1-5% Focus: -.01 to +.01"	
Titanium and Ti alloys are highly amenable to marking at this wavelength. Similar to aluminum, a black mark from the etching process is difficult to achieve. Various shades of gray can be made, from very dark gray to light gray. Annealed marks can also be made on titanium materials using the same processing parameter described for stainless steel. Depending on the Ti alloy, marks of various colors can be achieved by changing the frequency values for 1% up to 100%. It is common to see red, blue, green, orange, yellows and purple marks, depending on the frequency selected.			
Plated Metals			
Etching/Marking	600 - 1200 DPI	Speed: 15 - 20% Power: 100% Frequency: 1 - 5% Focus: -.09 to -.100" +.09 to .100"	
Metals are often plated to assist with conductivity, to provide a protective coating against rust and elements and for aesthetic purposes. Plating thickness will depend on application and purpose. Most of the plated metals processed through the applications lab are electronic components (to enhance conductivity) and various fittings (protection against environment & rust). The typical plating thickness varies from .001" up to .005". Our recommended settings for general metal engraving works well for ablating through the plating; exposing the base metal. Ablating the plating will also provide high contrast. Using an oxidizer will enhance the look. Our recommended settings for polishing of metals are a good starting point where ablating through the plating isn't an option. This is likely the most common plated metal application as exposing the raw metal underneath will break continuity and / or expose the bare metal to rust and other elements. Note that the contrast of polishing of plated metals won't be as consistent or contrasting as a direct ablation. Multiple passes will help and end results will vary based on the metal used for plating, thickness of plating & size of mark. Our recommended settings for annealing will often work for plated metals where the plating has a thicker wall and material used has high levels of carbon or metal oxides.			

APPENDIX B: MATERIAL SETTINGS

Fusion Ascent Suggested Material Settings (Fiber)			
Material	DPI/Freq.	30 watt	60 watt
Powder Coating			
Etching/Marking	600 DPI	Speed: 25 - 30% Power: 100% Frequency: 100% Focus: +.05 to .07"	
Two to three passes are suggested (one pass to ablate the powder coating, 2nd or 3rd pass to polish up the metal underneath). A little less power, higher frequency and less focus adjustment will be required for the 2nd or 3rd pass, depending on the base metal. The idea is to ablate then polish. An alternative to running two or more passes is to run one pass and then use a common cleaner such as Simple Green or a citric-based cleaner with short, stiff bristle brush to scrub out the residual material remaining in the mark area. If using this technique, it may be necessary to raise or lower the marking table from around 0.07" to 0.10".			
Deep Metal Engraving			
	1200 DPI	Speed: 20% Power: 100% Frequency: 1% Focus: 0	
Multiple passes. Slower speeds tend to erupt material rather than ablate.			

- **These are only guidelines:** Brightness or darkness of a mark is a matter of personal preference and can be very dependent of the type of material being marked. As such, there is no "correct" setting. Working with the four different fiber settings becomes fairly intuitive in a very short period of time for most users. If you have a material that is not listed, try to compare it to similar materials listed and use those settings as your starting point.
- **Speed Settings:** The speed setting scale of 1% to 100% is not linear – i.e. 100% speed will not be twice as fast as 50% speed. This non-linear scale is very useful in compensating for the different factors that affect engraving time.
- **Power Settings:** The power settings are linear – i.e. 50% power is half as much as 100% power.
- **General Metal Engraving / Base Settings:** In the world of metals the grade, type, hardness and chemical composition are endless. Metal alloys are engineered for specific applications and have their own strengths and weaknesses. Metals can be engraved at just about any settings. Of course, there are many variables to consider for metal engraving. The lasers wattage, hardness of metal, desired mark (etch, polish, anneal) and the required time/contrast/depth will have to be considered when deciding on the final settings.
- **General Annealing Settings:** Producing an annealed mark is very dependent on the material being out of focus. Run the laser at slow speed and full power then adjust the focus while the machine is running until you achieve the annealed mark you need.

APPENDIX B: MATERIAL SETTINGS

- **Test your material:** If you do not achieve the results you are looking for with the recommended settings, try resending the job and start by changing only one variable at a time. Changing only one variable at a time will help to determine the correct setting for your material.



- Laser settings can sometimes be confusing because many materials can be marked over such a broad range of settings. If you have difficulty in finding the correct setting you can send a sample to the Epilog Laser Applications lab. We will determine if the material can be marked and provide appropriate setting for your laser.
- To print a copy of these settings to keep next to your laser, go to www.epiloglaser.com/material-settings.

APPENDIX C: SYSTEM CALIBRATION

Calibrating the Auto Focus

Running the Focus Calibration Wizard

The Focus Calibration Wizard allows the laser system to automatically determine the optimal focal height for the installed lens. This process engraves a test pattern on anodized aluminum and identifies the focus position that produces the brightest mark. Running the calibration ensures accurate engraving and cutting performance.




Note: These steps will walk you through calibrating the auto focus of a Fusion Ascent with a CO2 laser only.


1. Open the Settings Menu by clicking the Gear icon in the upper-right corner of the display.



2. Select the Focus menu.




3. Select the Lens Aperture. If prompted by the calibration wizard, select the lens aperture used by your machine. If the wizard does not ask for this information, you may skip this step.
4. Choose CO2 Focus to begin the focus calibration wizard.




APPENDIX C: SYSTEM CALIBRATION

5. Start the Calibration Wizard. Click Proceed to continue.




6. Select Standard to run the automated focus calibration.




Note: Use the standard focal height lens. Accessory lenses such as the 4" lens require the Advanced Workflow.

7. Insert Calibration Material. Insert a piece of anodized aluminum into the machine and press Trace.




Note: Use 0.025" thick anodized aluminum.

8. Align the Material. Ensure the material is positioned directly under the traced outline, then click Proceed




APPENDIX C: SYSTEM CALIBRATION

9. Press Prepare, then click Proceed.




10. Click Proceed to begin the engraving job.



11. Allow the laser to complete the calibration engraving.
12. Select the Brightest Mark. Find the number

corresponding to the brightest engraving mark on the test pattern and enter it on the display.



13. The focus calibration process is now complete.

Advanced Workflow

The Advanced Workflow is intended for users who cannot complete the standard calibration process, are using an accessory lens such as a 4-inch lens, or prefer a manual calibration method. This option provides greater control over the calibration process by allowing manual adjustment of focus settings and engraving parameters.

During the advanced calibration procedure, you will select custom speed and power settings, enter the material thickness, and place your test material in the machine. The laser will engrave a 2x2 pattern while you manually raise and lower the engraving table. By adjusting the focus height during the job, you can identify the position that produces the brightest engraving mark. This method allows fine-tuning of the focal point and is especially useful when calibrating non-standard lenses.

APPENDIX C: SYSTEM CALIBRATION


Camera Calibration



Important Notes:

- All focus calibration procedures must be completed before performing a camera calibration to ensure accurate results.
- Camera calibration is only necessary if recommended by Epilog's Technical Support.
- Before beginning, reboot your machine if you have recently run any jobs.
- An official Epilog Calibration Mat is necessary for the Overhead Camera process.
- If the mat is curled, allow it to sit on a flat surface until it is perfectly flat. An unrolled, flat mat is essential for accurate results.
- It is advised to remove the calibration mat from the cardboard tube it is shipped in and laying it checkerboard side down on a flat surface at least an hour before completing the camera calibration. This ensures that the calibration mat will lay flat in the engraver and will result in a more accurate camera calibration.


Camera Calibration Mat



Carriage Camera Calibration


The following procedure must be performed first for all **Fusion Ascent** machines. Turn on the engraver, and let it complete the startup process.

14. On the display, press the gear icon to enter the Settings Menu.




APPENDIX C: SYSTEM CALIBRATION

15. Long Press the **“Settings”** text for 2-3 seconds to enter the Advanced Settings Menu.



16. Click on **“Calibration”** followed by **“Calibrate Cameras”** to enter the Camera Calibration menu. If using 1.1.2.8 or older, just tap **“Calibrate Cameras”**.



17. Place an 8” x 5” (200mm x 125mm) piece of anodized aluminum in the top left corner of the table.
18. Close the top door of the engraver.
19. Press OK to begin the carriage camera calibration and the engraver will move the table to the appropriate focal height for calibration.
20. The engraver will mark the anodized aluminum with a pattern that the carriage camera analyzes for calibration. Once the job is complete, a success message should appear.
21. Follow the on-screen prompts to continue to the overhead camera calibration.

Overhead Camera Calibration

1. Install Mat: Place calibration mat in the upper-left corner of the table. Ensure the green circle is in the corner.
2. Run: Close doors and press OK.
3. Follow the prompt and close the top door of the engraver.
4. Allow the process to run until completion. The camera at the laser head will take pictures of the mat to calibrate itself. This process takes several minutes.
5. Once the calibration has successfully finished, a dialog will appear. The “Reprojection error” will be listed and is used to determine the quality of the calibration. The lower the value, the better. If the reprojection error is above 2.0, the user will see an error “Calibration unsuccessful. Error too high”. A value of 0.6 or lower is desired.

APPENDIX C: SYSTEM CALIBRATION

Machine Settings:

- **Acceleration Match Offset [cnts]**
 - Number of encoder counts to delay firing laser when accelerating. Used for raster quality adjustments
- **Deceleration Match Offset [cnts]**
 - Number of encoder counts to delay firing laser when decelerating. Used for raster quality adjustments
- **Bed Margins [in]**
 - The margins around the bed, in inches that the carriage can travel to.
 - Format is as follows: TOP,LEFT,BOTTOM,RIGHT
- **Bed Size [in]**
 - The size of the bed in the machine in inches
 - Format is as follows: WIDTH,HEIGHT
 - Requires "Home Axis" to take effect
- **Disable Table Homing**
 - Setting to disable homing the table when the machine boots. For optimal operation, leave this at a value of 0
 - A value of 1 will disable table homing
 - Will take effect after reboot
- **Rotary Encoder [cnts/in]**
 - The number of encoder counts per inch of travel for the rotary device
 - Requires "Home Axis" to take effect
- **X Axis Encoder [cnts/in]**
 - The number of encoder counter per inch of travel for the X Axis
 - Requires "Home Axis" to take effect
 - Must recalibrate cameras if this changes
- **Y Axis Encoder [cnts/in]**
 - The number of encoder counter per inch of travel for the Y Axis
 - Requires "Home Axis" to take effect
 - Must recalibrate cameras if this changes
- **Home Offset [in]**
 - The offset of the table origin, relative to the X and Y limit switches
 - Requires "Park Axis" to take effect
 - Must recalibrate cameras if this changes
- **Joystick Center X**
 - The center X position of the joystick, in joystick units
- **Joystick Center Y**
 - The center Y position of the joystick, in joystick units
- **Joystick Deadzone [%/100]**
 - The percentage of dead zone around the center of the joystick
- **Joystick Limit X**
 - The MIN and MAX limits for the X axis of the joystick, in joystick units
 - Format is as follows: MIN,MAX
- **Joystick Limit Y**
 - The MIN and MAX limits for the Y axis of the joystick, in joystick units
 - Format is as follows: MIN,MAX
- **Laser Match [cnts]**
 - Adjustment to synchronize left to right and right to left raster lines. Units are in number of encoder counts
- **Laser Match Offset [cnts]**
 - Offset of the raster data in X. Used to align raster and vector if needed. Units are in number of encoder counts
- **Velocity Match Offset [cnts]**
 - Offset of the raster data proportional to velocity. Units are in number of encoder counts
- **Park Position [in]**
 - The position in inches to park the laser head when the machine is idle
 - Requires "Park Axis" to take effect
- **Plunger Offset [cnts]**
 - The number of table encoder counts from the laser zero focus position, to the auto focus plunger
- **Rotary Offset [in]**
 - The offset of the rotary origin, relative to the X and Y limit switches
- **Rotary Table Height [in]**
 - The distance in inches to clear the rotary device
- **Scale [mm/in]**

APPENDIX C: SYSTEM CALIBRATION

- A scale factor to adjust the scale of the X and Y axis
- Format is as follows: X,Y
- Requires “Home Axis” to take effect
- Must recalibrate cameras if this changes
- **Table Switch Locations [cnts]**
 - A list of the locations in which the table switches were located
- **Table Current [A]**
 - The current in Amps to run the table drive
- **Table Resolution [cnts/in]**
 - The number of encoder counts per inch of travel for the table
 - Must “Home Table” if this value is changed
- **CO2 Tickle Duration [us]**
 - The duration of the laser tickle pulse in microseconds
- **CO2 Tickle Frequency [Hz]**
 - The frequency of the laser tickle pulse in hertz
- **CO2 Tickle Holdoff [us]**
 - The duration in which the laser tickle is stalled after a laser pulse in microseconds
- **CO2 Pulse Stretch [us]**
 - The amount to stretch all laser pulses in microseconds
- **Table Focus Offset [cnts]**
 - The distance in table encoder counts from the top crash switch, to the laser focus position
- **RHS Y Skew [cnts]**
 - The number of encoder counts to skew the right hand side of the Y axis after homing
 - Requires “Home Axis” to take effect
- **Air Assist Delay [s]**
 - The number of seconds to delay turning ON and turning OFF the air assist before and after a job finished
 - Format is as follows: ON,OFF

INDEX

Index

Symbols

10/100 Network Interface Card 61
21 CFR 1040 7
32-bit Operating System 61
110 Volt 22
220 volt 22
240 Volt 22

A

Air Assist 1, 12, 44
 Fire Warning 1
Air Assist Pump 21
Air-Cooled 19
Air Filter. *See* Exhaust Fan
 Laser Tube 19
Air Temperature 19
Alumamark 71
Aluminum (Bare) 74
Anodized Aluminum 71, 74
ANSI 5
Auto Focus 38, 39, 44, 45, 46
 Plunger Mode 45
 Thickness Mode 45

B

Bearings 59, 60
Belts 59, 60
Brass 74

C

Calibration 79
 Auto Focus Calibration 79
 Dual Source Focus 83
Camera System. *See* IRIS Camera Positioning System
Centering Point 38
Certification/Identification Plate 7
Class A 63
Cleaning and Maintenance 49–57
 Optics 51
 Vents 56
CO2 Laser Source 62
Computer Recommendation 61
Control Panel 31
 Delete Button 34
 Display 31
 Focus 32

 Focus Menu 39
 Go/Stop Button 31
 Job Storage 42
 Joystick 40, 41
 Pointer 33
 Reset Key 32
 Status Indicator 31
Cooling Requirements 19
Cork
 Settings 71

D

Display 31
Door Interlocks
 Interlock Safety 7
Driver Updates 29
Dual Source
 Calibrating Focus 83

E

Electrical Requirements 22, 59, 60
 Electrical Power 15
Emergency Stop 46
Ethernet 15, 22, 59, 60
Exhaust 20, 21, 47
 CFM 20
Exhaust Fan 20, 47
 Blower Switch 20
 Connection 20
Exhaust Plenum 47

F

FCC 63
Fire Warning 1, 8
Focus function 32
Focus Menu 39
Front Access Door 47

G

Glass 71
Go/Stop Button 31. *See also* LED Status Graphics Card 61

H

Halotron Extinguisher. *See* Fire Extinguisher
Home Axis 36, 38
Home Table 36
Homing 31

I

INDEX

Idle 31
IEC 60825-1 7
Interlock Safety 7
IP Address 25, 26, 36
IRIS Camera Positioning System 43
 Using the IRIS Camera 43

J

Job Manager 36
Job Menu 33
Job Storage 42
Jog function 33
Jogging 31
Jog Menu 38
Joystick 42

L

Laserable Plastics
 Suppliers 74
Laser Safety 5
Laser System Classification 59, 60
Laser Tube 56
Leather 71
LED Status 32
Lens 67
Locking Coordinates 38

M

Manual Focus 45, 46
 Manual Focus Gauge 46
Material Settings 71, 74
Maximum Engraving Area 59, 60
Max Material Thickness 59, 60
Memory 42
Memory Buffer 59, 60
Mirror
 Cleaning 54
Motion Control System 59, 60

N

Network Settings 36
Nudge 38
 Nudge arrows 38

O

Open Architecture 61
Operating Modes 59, 60
Operating System 61
Operating Temperature 19
Optics

Cleaning 51–52
OSHA 5

P

Painted Brass 72
Park Axis 36, 38
Parking 31
Park Position 40
Photo Engraving 72
Plastic 72
 Engraveable 72
Plated Metals 75
Plunger 45
Pointer Button 33
Polishing Stainless Steel 74
Polyvinyl Chloride. *See* PVC
Powder Coating 76
Power 59, 60
 Connection 22
Power Connection 22
Power Label 8
Print Interface 59, 60
Processor Speed 61
Pulse
 Epilog Pulse 60, 61, 85
PVC 12

R

RAM 61
Red Dot Pointer 7, 46
Regulatory Compliance 7–13
Reset Key 32
Resolution 59, 60

S

Safety Enclosure 7
Safety Features 7–13
Safety Labels. *See* Warning Labels
Serial Number 65
Settings/Config menu 35, 36
Setup 15
 Choose Where to Locate the System 19
 Connecting Electrical Power 22
 Connecting the Exhaust 20
 Connect the Laser to Your Computer 22
 Driver Updates 29
 Register Your System 29
 Set the Fusion Pro's IP Address 25
 Unpacking the Laser System 16
 USB Connection 22
Software 62

INDEX

Speed and Power Control 59, 60
Stainless Steel 72, 74
 Annealing 74
 Etching/Marking 74
 Polishing 74
Standard Features 59, 60
Status Indicator 31
Storage 42
Surge Protector 62
System Settings 36

T

Technical Specifications 59, 60
Technical Support 65
Temperature 19
Test your material 73, 76
Thin Veneer 72
Titanium 75
Touchscreen. *See* Control Panel
Trace function 33

U

Unpacking the Laser 16
USB
 Connecting the Laser 22

V

Ventilation 59, 60
Vinyl 12

W

Warning Labels 7
Warranty 69
Wattages 59, 60
Wavelength
 CO2 Laser Source 62
Weight 59, 60
Wireless 27
 Disabling 41
 Enabling 41
 Setup 27
Wood 72

